Material Guide

Original Desktop Filament Extruder MK1 by ARTME 3D Version 19.06.22





The material guide of ARTME 3D's original desktop filament extruder MK1 is an open source project used under a CC BY-SA license:

You may:

- Use, modify and redistribute any content.

Under the following condition:

- Attribution: David Pfeifer from ARTME 3D
- Link my project: www.artme-3d.de
- Indicate what has been changed
- Publish under the same license

More details about the license see https://creativecommons.org/licenses/by-sa/4.0/

Support me:

The effort required to publish such a project as ARTME 3D's Original Desktop Filament Extruder MK1 is great. The development and the creation of the documentation have now required more than 1200 hours of work. All this to make the knowledge about the project available to all interested users for free, to live the open source idea. I can not earn these services with the sale of the kits. The rent for workshop, office and warehouse, as well as personnel costs and material costs are too high for that. If you would like to support me in developing and publishing projects of this kind, I would appreciate a small donation. This can be done in different ways:

- Buy a donation in my webshop: artme-3.de/shop
- Support me on Patreon: https://www.patreon.com/artme3d
- Send me a donation amount via Paypal to paypal@artme.de

You can follow my developments through various sources:

- On the web at www.artme-3d.de
- On Instagram at instagram.com/artme3d
- On Youtube at https://www.youtube.com/c/ARTME3D

Table of Contents:

1. drying	Page 3
2. grade purity and color separation	Page 3
3. Grain size and flowability	Page 4
4. cleanliness	Page 5
5. storage	Page 5
6. processing temperatures guide values	Page 5
7. addition of color pigments/masterbatches	Page 5
8. extruder start-up with shredded 3D printing waste	Page 6
9. processing 3D printing waste into granules	Page 6
10. shredding filament leftovers	Page 9

1. drying:

Plastic granules should be dried before processing, as many plastics absorb moisture from the air, which negatively affects extrusion and causes bubbles in the filament. If you do not have access to a drying cabinet or granulate dryer, this can also be accomplished with a commercial convection oven. Here you can find empirical values for temperature and drying time depending on the material: (Source: 3d-druck-comminuty.de) Experience has shown that the drying time in ovens can be a few hours longer than indicated here.

Material	Temperature	Duration hrs
PLA	45°C	> 4h
ABS	60°C	> 2h
PETG	65°C	> 3h
Nylon	70°C	> 8h
ASA	60°C	> 4h
TPU	50°C	> 4h
PVA	45°C	> 4h

2. grade purity and color separation:

Keep plastics sorted by type. Never mix different types of plastics. It is also advisable to separate materials by manufacturer. Even if you process one type such as PLA, the properties may be different from other manufacturers.

Separating by color also makes sense, as you can then create a new color if you specifically mix two or more colors. If you mix too many colors, you will get a brown or gray filament.

3. Grain size and flowability:

For ready-to-use (industrial) granules/pellets:



Each grain must not be longer than 5mm on the longest side. All other sides must be smaller than 4mm.

Industrial granules trickle well. Therefore, the hopper part 2 should be used to ensure a uniform filling neveau in the feed zone.

For self-produced granules (shredded 3d pressure drop):



Each grain should not be longer than 4.5mm on all sides. This can be ensured by sieving the material before use. The sieve should have a mesh size of 4 to 4.5mm. Homemade granules must be mixed well homogeneously. Another criterion of homemade granules is their pourability. Compared with brand-new granules, homemade granules from plastic waste usually flow much less easily. It also tends to bridge. This means that cavities form in the pellets as they become wedged at narrow points in the hopper and therefore no material can reach the extruder screw, even though the hopper is apparently full. The design of the extruder is intended to prevent this. On the one hand, the shape of the hopper is designed for this, and on the other hand, a type of agitator is attached to the coupling between the extruder screw and the drive motor. This prevents bridging in the feed section. When using self-produced pellets, the hopper part 2 should be removed. When collecting 3D printing waste, please note the following: Thin strips, which result from a "brim" or skirt on the print bed, are difficult to shred and can obstruct the

material flow in the feed zone of the extruder. Therefore, please sort out such parts or do not collect them:



4. cleanliness:

Protect any type of granules from dust and contamination. Use containers with lids. The melt filter in the nozzle only ensures that the filament is processed on 3D printers with 0.4mm nozzle. Many other types of contaminants cannot be stopped by the filter or cause the filter to clog prematurely.

5. storage:

Store all forms of plastic granules in containers with lids. Ideally, the container should be as airtight as possible. Place a large bag of silica gel in the container to keep the material dry. Also store 3D printing waste that you collect for later processing this way.

6. processing temperatures guide values:

Current empirical values can be found in the "empirical values" for download at www.artme-3d.de/support.

7. addition of color pigments/masterbatches:

The mixing capacity of an extruder in this small design is limited. Coloring is possible but limited in homogeneity. There are masterbatches that negatively influence or interfere with the extrusion performance. Therefore, start only with a small amount and feel your way to a

maximum addition. The agitator screw on the extruder screw coupling should not be installed when using pellets with masterbatches.

8. Extruder start-up with shredded 3D printing waste (Only for version E1.5 to E1.7):

To extrude shredded 3D printing waste, proceed as follows:

- Heat up the extruder (e.g. PLA approx. 175-180°C).
- After heating up, start the extruder at a relatively slow speed (approx. 5RPM).
- Then increase the temperature again by about 20°C up. This increases the temperature in the feed zone, which supports homogeneous conveying of the shredded material.
- When the temperature is reached, lower it again to the processing temperature and increase the RPM. The material initially comes out of the die quite thin.
- Allow the extruder to run until the temperature and material flow have stabilized before starting to wind. This is the case when the material appears less fluid, expands more as it exits the die, and suddenly flows a little slower.
- Now you can start the rewind. (See operating instructions)

9. processing 3D printing waste into granules:

Shredding 3D printing waste usually requires powerful and expensive machines. In the following I would like to show several possibilities:

9.1 The most convenient solution with the best granule quality is a normal industrial shredder, also called a granulator or granulator. Such devices ideally have toothed cutting blades and an interchangeable screen, so that you can determine the granule size. However, this will take a little more money and often require a power connection.



9.2 An open source solution for powerful shredders comes from the Precius Plastic movement. Ready-made machines can also be bought in the online bazaar: https://bazar.preciousplastic.com. But even these devices are not very cheap:



9.3 On a small scale, a so-called side mill or sprue mill can also be used. Here is an example:



These types of mills can be found cheaply from time to time in classified ads or industrial auctions. These mills also have a built-in sieve. The disadvantage of these mills is that the inlet is quite small and larger 3D prints must be pre-shredded and a heavy current connection is also necessary.

9.4 An alternative to these large and expensive machines can be the grinding of 3D printed parts in a kitchen blender:



The first references in this area are the classic 575 mixer from Blendtec. The device is available for around 400€. The special feature is that the powerful motor in combination with the blunted blades and the container design beats the 3D pressure waste relatively evenly small. Due to the short running time, little heat is generated. The material should still be passed through a sieve and can then be used in the extruder. However, only PETG has been tested so far. Cheap kitchen mixers do not fulfill this purpose. The power is not sufficient and the material can melt due to heat development.

9.5 A good and cheaper approach is a roller shredder:



It is important to use a shredder with a slowly rotating knife roller. (silent garden shredder) Normal, fast rotating knife shredders would melt the plastic. However, I have found that very cheap units put some metal debris into the grind, which can discolor the material and cause the melt filter to clog early. Therefore, you should rather go for devices in the price range of 200 to 250 euros. But in general, these devices work quite well, they have good power and can be operated on a normal power outlet. High-quality roller shredders are also quite quiet. However, there is also a limit here in the size of the waste to be processed. Large pieces must be pre-shredded with a hammer or saw. First tests were very promising, though. I am working on building a kind of sieve support into such devices. This will turn the material in a circle and crush it until it can fall out through the sieve. This produces usable grist:



However, I currently lack budget and time. If you would like to support me in the further development of the shredder, I would be happy about a small donation via Paypal to paypal@artme.de. I will publish my developments continuously and offer kits if necessary.

10. shredding filament leftovers:

Filament leftovers are relatively difficult to shred with some types of shredders in order to process it in the extruder. Therefore there is the possibility to shred the filament with a "pelletizer". There are some do-it-yourself solutions on Thingiverse and Youtube. I can recommend for example the "High speed filament pelletizer".

by "fred_barbosa" at www.thingiverse.com. This allows you to quickly process a homemade filament that may not meet the required tolerances into pellets for further processing.